

Sprinkler Zones and Heads Mapping
Updated 9-22-2015

Controller - Installed 5-19-2015. Hunter X-Core 6-zone

Electrical - Replaced GFI Outlet with non-GFI Weather Resistant and new Cover 5-20-15

Sprinkler Zones - Note Zones have changed with new controller

Zone 1 - Island in Center of Community - ZONE HAS 18 ROTOR HEADS

Zone 4 - West Side Front - Grass by Road - ZONE HAS 12 HEADS (ROTOR AND/OR SPRAY).

Zone 5 - Around the Fenced Area

and East Side Shrubs (by Fence) - ZONE HAS TOTAL OF 26 SPRAY HEADS

Zone 2 - West Side Shrubs (by Fence) - ZONE HAS TOTAL OF 27 SPRAY HEADS

Zone 3 - East Side Front - Grass by Road -ZONE HAS 7 ROTOR HEADS

Zone 6 - For Hose Bib

Pressure Reading (Gauge)

55 lbs.

70 lbs.


55 lbs.

50 lbs.


80 lbs.

80 lbs.

ZONE 1 - ISLAND SPRINKLER HEADS



ZONE 4 - WEST SIDE GRASS




Island Updates


Rotor I-18 - New April 2015

NLT replaced 3 rotors I-7, I-15, I-17 Sept 22, 2015


ZONE 5 - ENTRANCE ISLAND AND EAST SHRUBS



ZONE 2 - WEST SHRUBS



ZONE 3 - EAST GRASS



Island Updates

NLT Replaced 2 rotors - #1 & #4 - 9/22/15
 #5 sticky. #3 needs reduced end points